

BrightSign Setup Instructions



STEP ONE: Install Appropriate Software

1. Visit the Hypersign™ Support Center within the Hypersign™+ web portal and download the BrightSign app software: “BrightSign Setup Production.zip”
2. Unzip “BrightSign Setup Production.zip” either to your computer or directly to the SD card.
3. You should have three folders named “appcache”, “db”, and “sign”, and three files: (1) .DS_store (2) autorun.brs (3) autozip.brs
4. Copy these to your player SD card (if they are not already there).
5. Make sure your BrightSign player is powered off and not plugged in.
6. Connect the HDMI cable to the player and to your display.
7. Connect an Internet LAN cable to the LAN port on the Player.
Note: Player MUST be hard-lined to the local network. Wireless doesn't work yet.
8. Insert your SD card into the card reader on the BrightSign player.
Note: You may need an adapter if you have a micro SD card.

STEP TWO: Launching & Pairing Hypersign™+

1. Power up the BrightSign player once it is connected to your local Internet network and display. When the player has completed booting up, a six-digit pairing code will appear.
2. Use another computer to visit the device manager in the Hypersign™+ web portal.
 - Once in the device manager, click the “Add New Device” button.
 - Enter the six-digit pairing code provided to you on your BrightSign Player.
 - Set the device resolution to match the BrightSign display settings.
 - Name the device, select license types, etc.
 - Once you click submit, a device card is automatically generated.
3. Now your device is paired to your Hypersign™ account, and you can begin publishing your content immediately.